



Hart Equipment Cleaning Recommendations

Hart equipment may be wiped with a 50% or higher clear, fragrance-free, isopropyl alcohol solution and a lint-free wipe. Do not use ammonia or detergent-based solutions as these may be harmful to the screen or the plastics surrounding the display. To avoid spotting, make certain that equipment screens are wiped dry (do not leave puddles).

We encourage our customers to:

- Wipe polling place devices and booths with a lint-free cloth that has been slightly dampened with 50% or higher clear isopropyl alcohol (hand alcohol wipes are fine). It is best to do this for every voter.
- Provide hand sanitizer at the voter check-in station (so voters' hands are relatively clean when they go to the equipment).
- Use single-use, disposable, ear covers for device headphones.
- Additionally, poll workers and staff at poll book and laptop workstations should keep their hands clean and equipment wiped down regularly.