## **DS200 ELECTION DAY LOGIC AND ACCURACY**

Local Board Name: \_\_\_\_\_ Polling Place Number: \_\_\_\_\_ Election Date: \_\_\_\_\_ Today's Date: \_\_\_\_\_ Primary: D General: D

\_\_\_\_

DS200 Serial Number: \_\_\_\_\_\_ Unit Number (if applicable):\_\_\_\_\_

Note: If the expected test result is not observed, stop testing and notify the L&A Team Leader.

Step	L&A Test Steps	Data / Comments	Check
1.	<ul> <li>Prepare DS200 <ul> <li>Verify shipping tags</li> <li>Inspect DS200 for physical damage</li> <li>Inspect ballot box</li> <li>Insert empty Ballot Transfer Bin</li> <li>Ensure top doors of Ballot Transfer Bin are open</li> <li>Ensure metal bar is in the down position and the rear access flap is up.</li> </ul> </li> </ul>		
	Note: When this step is complete the DS200 Ballot Box lid should be open and the DS200 screen should be up. The DS200 should not be connected to AC power until step 2.		
2.	Connect unit to AC power making sure to use Tripp-Lite adapter.		
3.	If using a Backup Memory Stick it <b>must</b> be inserted now. Record the Backup USB Memory Stick serial number and unlock the rear access compartment cover. Insert Backup USB Memory Stick into the USB port located inside the rear access compartment. Lock the rear access compartment.	Backup Memory Stick Serial Number:	
4.	Unlock and open the front access compartment cover. Insert the Election Qualification Code Memory Stick into the <b>B</b> Slot and power on by pressing the power button inside the access panel. <b>Note: a configuration report will print</b> <b>automatically.</b>		

5.	Verify the correct election information including Qualification Code is shown on the Clear and Initialize screen in the <b>new row</b> . If the information is correct touch <b>Continue</b> .	Qualification Number: If information is not correct report this to your team leader immediately.
6.	Enter the Qualification Code provided by SBE when prompted and touch <b>Accept</b> .	
7.	On the Initialization Complete screen verify the correct Election information is displayed. If the information is correct remove the Election Qualification Code Memory Stick.	If information is not correct report this to your team leader immediately.
8.	Record the Election Definition Memory Stick Serial number.	Election Definition Stick Serial Number:
9.	On the <b>This voting device is not ready to be opened</b> <b>for voting</b> screen insert the Election Definition Memory Stick into slot B. When prompted enter the Election Code provided by SBE and touch <b>Accept</b> .	
10.	The screen will now display <b>This Voting device is ready</b> <b>for the poll to be opened</b> . Verify the Election definition found is correct.	If information is not correct report this to your team leader immediately.
	Note: Another Configuration Report will print now including information about the current election loaded.	
11.	Touch <b>Admin</b> located in the top right corner of the screen. On the Voting Device Status screen, verify the information referenced below and displayed under Election Status is correct and check the corresponding boxes. Note: not all information displayed is listed below.	If information is not correct report this to your team leader immediately.
	Election NameOElection DateOElection Qualification CodeOElection DescriptionOPolling place / IDO	

12	Under System Status verify or record as applicable the information referenced below:         Unit Serial:       O (verify against number previously recorded)         Public Count = 0       O         Protected Count:       O         Power Type: AC       O         Battery Status: Present       %         Firmware Version = 2.12.0.0       O	If serial number does not match number recorded in header information, notify your team lead.	
13	Touch <b>Log In</b> and enter the Administration Code when prompted. Touch <b>Accept</b> .		
14	From the left side menu touch <b>System Settings</b> and then touch 'Date And Time Options'. Verify Current Date, Current Time, and Current Time Zone are correct. See box to the right if any changes are required.	If any changes to the time, date, or time zone are needed make applicable correction make sure to touch <b>Apply</b> , <b>Back</b> , <b>Apply</b> , and then <b>OK</b> . Note: Correct Time Zone is ( <b>GMT-5:00</b> ) Eastern Standard Time (New York). Adjust for Daylight Savings Time if applicable.	
15	From the left side menu touch <b>Logout</b> and then touch		
	Exit on the bottom left side of screen.		
16	Touch <b>Open Poll</b> . Two Zero Totals Report will print. Verify all results on the reports are <b>0</b> .		
17.	Touch <b>Go to Voting Mode</b> . Verify Public Count displayed on the screen is <b>0</b> .	Public Count:	
18	From <b>Welcome. Please insert your ballot</b> screen scan the Test Deck including ballots created on the ExpressVote for this polling place. Make sure to test ballots in all four orientations.	Number of Ballots:	
19.	When done, verify Public Count matches number of ballots scanned.	Public Count:	
20.	Disconnect the unit from AC power. Verify the unit continues to operate on battery power.	If unit shuts down notify team lead.	
21.	Inside the front access compartment press the <b>Close Poll</b> button.		

22.	On the screen touch <b>Close Poll</b> . Two Ballot Accounting Status Reports and two Voting Results Report will print. Verify the printed results match the expected results.		
	Note: make sure to add in any ExpressVote Ballot Activation Cards totals to the Test Deck expected results.		
23.	Touch <b>Finished- Turn Off</b> . Allow the DS200 to shut down completely (the power button light will change from green to red and then off). Remove Election Definition Memory Stick.		
	Note: If using a backup memory stick allow additional time for saving results to the backup memory stick.		
24.	Upload the results to the Certified Network.		
25.	Reconnect to AC power.		
26.	Verify Election Definition Memory Stick serial number matches serial number recorded in step 8.	Election Definition Memory Stick serial number matches: O	
27.	Insert the Election Definition Memory Stick into slot B. Power on the DS200 by pressing the power button inside the front access compartment. Enter the Election Code when prompted and touch <b>Accept</b> .		
28	Verify correct polling place is shown on the top left of screen and election information displayed at the top center of screen is correct.		
	Note: A Configuration Report will print automatically.		
29.	Touch <b>Re-open Poll</b> and enter the Override Code when prompted. Touch <b>Accept</b> .		
30.	Touch <b>Clear Votes</b> and then touch <b>Clear Votes &amp;</b> <b>Continue</b> . Verify Public Count is reset to zero. Record Protected Count.	Protected count:	
31.	From the <b>You have successfully cleared the vote</b> <b>totals</b> screen touch <b>Report Options.</b>		

32.	Under <b>Report Type</b> select the <b>Zero Totals</b> radio button. Touch <b>Print Report.</b>	
	Note: <b>Report Format</b> and <b>Report Leve</b> l should be set to <b>Public</b> and <b>Polling Place</b> respectively.	
33.	A Zero Totals Report will print. Verify all results are zero. A Supervisor must verify that zero votes are shown for all contests.	Supervisor Initials:
34.	Touch <b>Cancel</b> and then touch <b>Don't Open- Turn Off</b> . The DS200 will power down.	
35	Remove Reports and staple to this form.	
36	Replace Paper Roll.	
37.	Close and lock the front access compartment. <b>DO NOT</b>	Tamper tape numbers:
	<b>REMOVE Election Definition MEMORY Stick.</b> Apply Tamper Tape to the front access compartment and record. Record the rear access compartment tamper tape number (apply if necessary).	Front Access Compartment:
		Rear Access Compartment:
38	Remove all test deck ballots from ballot transfer bin. Remove the Ballot Transfer Bin.	Seal Numbers:
	If Election Day Ballots are not packed and ready at this	Ballot Transfer Bin
	time, seal the Main Ballot Box and the Emergency Ballot Compartment.	Main Ballot Box
	If Election Day ballots are available at this time, you may	Emergency Ballot Compartment
	insert the packed and sealed Ballot Transfer Bin for this polling place at this time.	
	Record all applicable seal numbers.	
39.	Close and lock the screen of the DS200. Close and lock	Seal Number:
	the lid of the DS200. Apply a numbered seal to the lid and record the number.	Left Case Seal Number:
	Record the left side case tie and right side case tie seal numbers.	Right Case Seal Number:
	Move the DS200 to the staging area.	

Tester Name and Signature:	Date:

2016 L&A Checklist 03-14-16